



# Ehang GHOSTDRONE Aerial Plus 2.0 Battery Replacement

Replace the battery on your Ehang GHOSTDRONE Aerial Plus 2.0 to bring power back to your drone.

Written By: Edrees Nawabi



## INTRODUCTION

Are you having battery issues? Follow this simple guide to replace the battery on your Ehang GHOSTDRONE Aerial Plus 2.0.

---



### TOOLS:

- [iFixit Opening Tools](#) (1)
-

## Step 1 — Battery



- While the drone is facing forward, pinch the two tabs on the capsule, and pull it forward.

## Step 2



- The battery is in the back of the capsule.
- Pull the battery out from the back using one of the plastic tools to guide it out.

To reassemble your device, follow these instructions in reverse order.

